

Clean Card PRO, starter set, 25 control cards, PET bottle, picture card, hygiene quick test



Clean Card® PRO: Quick hygiene test in only 30 seconds!

Clean or not clean? The tricky thing about germs is that you cannot see them. They are invisible to the human eye and therefore, unfortunately, cleaning deficits are often not noticed at all, but now there is a remedy. The Clean Card® PRO makes protein and detergent residues visible, which can be a breeding ground for germs. It's easy and in only 30 seconds!

The Clean Card[®] PRO is an excellent instrument for everyone who works in hygienesensitive areas. It is a simple and reliable control measure that can be carried out in a flash at any time.

quick and easy self control to check the cleaning quality reveals cleaning/disinfection deficits - in only 30 seconds ! optimises hygiene and cleanliness in the company ideal as a training tool for sensitising staff additional motivation through fast visualisation ideal for meeting the legal requirements according to HACCP and good hygiene practice can be

Products for the electronic industry





integrated into ISO, IFS, BRC or internal hygiene plans with reference to DIN 10516 documentation with Clean Card[®] PRO test protocol simple subsequent cleaning saves time, trouble and money can be disposed of with the residual waste recommended by the German Federal Association of Food Inspectors

How the Clean Card® PRO works...

1.) preparation:

Pour fresh drinking water (cold or room temperature) or distilled water into the plastic bottle provided. Seal the bottle with the appropriate spray head. Then remove the Clean Card[®] PRO from the box, but without touching the perforated yellow part of the test card with your fingers.

2.) Procedure:

Moisten the surface to be tested by spraying the surface briefly with water two to three times. Rub the test card vigorously several times over the moistened area and press the perforated part of the card firmly against the area to be tested. The test card must absorb all moisture. Notes: The test area should ideally be approximately 10 x 10 cm. Spray the water only onto the surface to be tested and never directly onto the test card. Use the Clean Card[®] PRO only once, as a used test does not give reliable results.

3.) Evaluation:

Wait 30 seconds and compare the color reaction with the attached evaluation card. As proof of a contaminated area a colour change in only one of the circles is sufficient. The Clean Card[®] PRO is a protein test, which is based on a protein quantity from approx. 25 μ g / 100 cm ² reacts. The darker the blue of the color circles, the more protein was detected. Scope of delivery:

25 control cards Plastic bottle with spray head Evaluation table Instruction manual

- Quick hygiene test in only 30 seconds
- for checking the cleaning quality
- easy to carry out abrasion test
- recommended by the Federal Association of Food Inspectors
- Documentation with Clean Card PRO test protocol

item number	WL49677
model	31510
manufacturer	FRANZ MENSCH
manufacturer item number	31510
order unit	1 set
content unit	1 set

Products for the electronic industry

