

Tickopur deoxidation solution, J 80 U / 1 litre



TICKOPUR J 80 U for deoxidation and cleaning of non-ferrous and precious metals in trade, industry and laboratories. When used properly, a fast and material-protecting deoxidation and cleaning is guaranteed.

TICKOPUR J 80 U is especially suitable for deoxidation and cleaning in SONOREX ultrasonic units, but also for immersion and wiping application.

TICKOPUR J 80 U removes

Oxide and sulphide layers, fluxes, oils and greases from parts made of precious metals and their alloys, copper, bronze, brass such as jewellery, coins, art objects etc. Jewellery with pearls, corals and amber as well as gold-plated and silver-plated objects can be attacked. Deoxidize different metals in separate containers

- Liquid
- Ready for use
- For ultrasonic application
- pH 1,5

- Very short deoxidation time
- With tarnish protection
- Biodegradable
- Application with ultrasound
- Sonication time: less than 30 seconds
- Temperature: room temperature
- Use insert vessel!

item number	WL34059
model	J 80 U / 1 Liter
manufacturer	Dr. H. Stamm
manufacturer item number	880
order unit	1 piece
content unit	1 piece